
FIG. 1






FIG. 3





FIG. 4



(TO NEXT STEP TO EXECUTE NEXT STATEMENT)

FIG. 5


START

DESCRIBE FOLLOWING SETTINGS IN EACH STATEMENT OF BASIC (OUT STATEMENT)

- 1 EXECUTE/CANCEL AUTOMATIC OPTIMIZATION FOR FLASH MEMORY IN RELATION TO EXECUTION OF SPECIFIC STATEMENT
- 2 EARLIER/LATER THAN EXECUTION OF SPECIFIC STATEMENT IN THE CASE OF EXECUTING OPTIMIZATION
- ③ OPTIMIZATION SIZE IN THE CASE OF EXECUTING OPTIMIZATION

END

S31







DESCRIBE FOLLOWING SETTINGS (OUT STATEMENT)

- 1 EXECUTE/CANCEL AUTOMATIC OPTIMIZATION FOR FLASH MEMORY AT DESIGNATED DATE/TIME
- 2 DETAILED DATE/TIME FOR OPTIMIZATION IN THE CASE OF EXECUTING OPTIMIZATION
- ③ OPTIMIZATION SIZE IN THE CASE OF EXECUTING OPTIMIZATION

END

S51